

## Model 260: weight indicator with one set-point and loading steps for Unifeed mixers



### Easy, precise and with good price

The indicator mod. 260 is the result of Perin Weighmaster's experience in proposing reliable and easy weighing solutions. The user can decide whether he wants to work with partial weighings, to set a single loading/unloading point or a sequence of loadings/unloadings with alarm. This sequence is easy to set, in fact it does not require complicated programming procedures. For its functionality, this indicator is applied both to mixer wagons and to truck mixer wagons. The indicator is housed in an A.B.S. hermetic box and is provided with automatic and manual tests which indicate the battery voltage, a short circuit on the alarm output, damaged cables or sensors.

### FEATURES

Power supply 12/24 Volts 0,3 Amp

Backlit LCD with 5 digits 38 mm high for the weight value and 2 digits h 14 mm high for loading/unloading steps

Max resolution 24 bits

Increment 1 - 2 - 5 - 10 - 20

Announcers: total/net, set, load/unload, step, lb, kg

Pre-alarm and alarm for each loading/unloading

Tare, calibration, increment and battery test by keys

MIL type connectors

Connector StarBus of series

Associable remote displays: LCD REM/40A numeric black digits h 40 mm

LED REM/40B numeric red digits h 40 mm

LED REM 57 numeric red digits h 57 mm

LED ALFA alphanumeric red digits h 30 mm